



NO.		ENGLISH NAME	Quantity
1	8CE-07B	E TYPE RING	1
2	8128-462201	CHAIN GEAR	1
3	8342-462304	TENSION SPRING	1
4	8349-491101	WOOL RING	1
5	8005-491201	GRIP	1
6	8440-491201	OILTANK SUBASSEMBLY	1
6-1	8061-491201	INPUT OIL TUBE	1
6-2	8213-471001	FIXATION CONNECTOR	1
6-3	8326-462701	SPONGE	1
6-4	8348-462701	OIL TANK CONNECTOR	1
6-5	8208-462503	OUTPUT OIL END SEAL RING	1
6-6	8165-491201	OIL TANK	1
7	8186-463101	OIL BOARD	1
8	8440-462506	OIL TANK CAP ASS	1
8-1	8335-463102	VALVE	1
8-2	8208-463101	SEARING RING	1
8-3	8020-462502	OIL TANK CAP	1
8-4	8185-462502	OIL TANK COVER	1
9	8312-491201	SWITCH BUTTON	1
10	8121-462201	GEAR	1
11	8416-462501	CAPACITOR	1
12	8342-462306	SPRING	1
13	8007-462301	CLASP	1
14	8042-462201	SWITCH	1
15	8422-462501	CABLE	1
16	8332-35301	CABLE HOOD	1

17	8SJAB04-12B	SCREW	1
18	8184-302201	Cable board	1
19	8162-491297	LABEL	1
20	8206-462501	SCRW	1
21	8SJAB50-20B	SCREW	1
22	8004-491201	MOTOR COVER	1
23	8162-491296	LABEL	1
24	8005-462503	GRIP	1
25	8006-491201	LEFT HOUSING	1
26	8181-462503	WIND BOARD	1
27	8162-491207	WARNING LABEL	1
28	8324-462203	BRAKE WASHER	1
29	8SJAB50-20B	SCREW	1
30	8SJAB40-16B	SCREW	1
31	8063-462502	Bush	1
32	8061-462901	Tube	1
33	8063-462302	Connector	1
34	8SJAB03-12B	SCREW	1
35	8204-462201	RUBBER RING	1
36	8440-491202	MOTOR	1
36-1	8SNAB30-08B	SCREW	1
36-2	8181-481002	HOLDER BOARD	1
36-3	8406-472101	CARBON BRUSH	1
36-4	8409-481001	BRUSH HOLDER	1
36-5	8NA-04D01	NUT	1
36-6	8WF-04B	RING	1
36-7	8291-481001	MOTOR SUPPORT	1

36-8	BC-220707	627Z BEARING	1
36-9	8405-491201	STATOR	1
36-10	8402-481301	ROTOR	1
36-11	BC-261008	6200Z BEARING	1
36-12	8182-491201	WIND SCREEN	1
36-13	8321-481002	WASHER	2
36-14	8324-481001	WASHER	2
36-15	8206-481001	SCREW	1
36-16	8187-491201	SUPPORT BOARD	1
36-17	8SJAB40-16B	Screw	4
36-18	8333-491201	BUSH	1
36-19	8123-462201	MOTOR GEAR	1
36-20	8ND-08D	FLANGE NUT	1
37	8024-491201	Dust Cover	1
38	8SJAB04-14B	Screw	1
39	8440-472204	OIL PUMP ASS	1
39-1	8123-472201	WORM WHEEL TOOTH	1
39-2	8121-472201	WORM WHEEL	1
39-3	8292-472202	PLUNGER SHELF	1
39-4	8211-472202	PLUNGER TUBE	1
39-5	8336-472202	OIL PUMP	1
39-6	8342-491201	Spring	1
40	8SJAB30-12B	Screw	1
41	8061-462901	Tube	1
42	8213-462502	Connector	1
43	8006-491202	RIGHT HOUSING	1
44	8SJAB05-16B	Screw	1

45	8SJAB05-16B	Screw	1
46	8181-491201	BUFFER PLATE	1
47	8181-463101	GUIDE BAR	1
48	8344-463101	SAW CHAIN	1
49	8331-463101	BAR COVER	1
50	8261-463101	Spanner	1
51	8440-472202	OUTSHAFT ASS	1
51-1	8NG-08D	SCREW	1
51-2	BC-220807-ST	608Z BEARING	1
51-3	8123-462202	OUTSHAFT GEAR	1
51-4	8063-462201	AXLE SLEEVE	1
51-5	8342-462301	SPRING	1
51-6	8085-472202	OUTPUT SHAFT	1
52	BC-261008	6200Z BEARING	1
53	8162-491298	Label	1
54	8202-462205	WASHER	1
55	8SJAN04-10B	SCREW	7
56	8206-462201	Screw	1
57	8347-491303	RIGHT HOUSING INSERT	1
58	8207-463101	Tension Nut	1
59	8207-491201	TENSION SPRING	q
60	8208-462204	SEARING RING	1
61	8440-491203	Side Cover ass	1
61-1	8208-462305	ring	1
61-2	8021-491701	Side Cover	1
61-3	8334-463101	Bush	1
61-4	8162-491297	Label	1

62	8ND-08D	Nut	1
63	8185-463101	Nut Cover	1